


Parker Eclipse Machinists' Vises

Stationary Base



Fitted with renewable and fitted tool steel jaws. Set screw and spring in handle. Extra strong screw and nut. Fits the bench.

No.	Each	Width Jaw Ins.	Vise Opens Ins.	Wt. Lbs.	No.	Each	Width Jaw Ins.	Vise Opens Ins.	Wt. Lbs.
953	10.00	3	4½	23	954½	15.50	4½	7	63
953½	11.25	3½	5½	35	955	20.00	5	8	85
954	12.75	4	6½	46	956	39.00	6	10½	132
					958	75.00	8	13½	245

Parker Eclipse Machinists' Vises

Swivel Base




Fitted with hex wrench, positive locking control, giving 360 degrees gripping power, renewable and fitted tool steel jaws. Set screw and spring in handle.

No.	Each	Width Jaw Ins.	Vise Opens Ins.	Wt. Lbs.	No.	Each	Width Jaw Ins.	Vise Opens Ins.	Wt. Lbs.
973	13.00	3	4½	26	974½	20.00	4½	7	76
973½	15.00	3½	5½	42	975	30.00	5	8	104
974	17.00	4	6½	59	976	52.00	6	10½	157
					978	98.00	8	13½	298

Parker Victor Machinists' Vises


Swivel Base Swivel Jaw



Removal of pin permits top of back jaw to be swiveled to hold odd shaped pieces for filing, etc. Removable steel jaws. Solid underportion.

No.	Each	Jaw Opens In.	Wt. Lbs.	No.	Each	Jaw Opens In.	Wt. Lbs.
383½	20.00	3½	5	385	35.00	5	7
384	24.00	4	5	386	60.00	6	9½

Parker Woodworkers' Vises



The jaws are deep and flat without any separations. Solid steel strengthening bar cast entire length of slide. Solid cast underportion. Tension spring in handle. 360-degree swivel gripping power, readily changed to left-hand operation.

No.	Each	Base	Jaw In.	Depth Face In.	Opens In.	Wt. Lbs.
654½	17.50	Stat.	4½	2¼	7	64
674½	22.50	Swivel	4½	2¼	7	77

Parker Superior Machinists' Vises

Swivel Base



Renewable steel jaws. Solid steel strengthening bar cast entire length of slide. Solid cast underportion. Tension spring in handle. 360-degree swivel gripping power, readily changed to left-hand operation.

No.	Each	Jaw Opens In.	Wt. Lbs.	No.	Each	Jaw Opens In.	Wt. Lbs.
823	16.25	3	4	824½	25.00	4½	8
823½	18.75	3½	6	825	37.50	5	8½
824	21.25	4	7	826	65.00	6	9½

Parker Superior Machinists' Vises



Stationary Base

Renewable steel jaws. Solid steel strengthening bar cast entire length of slide. Solid cast underportion. Tension spring in handle.

No.	Each	Jaw Opens In.	Wt. Lbs.	No.	Each	Jaw Opens In.	Wt. Lbs.
803	12.50	3	4	805	25.00	5	8½
803½	14.00	3½	6	806	48.75	6	9½
804	15.75	4	7	808	93.75	8	13½
804½	19.25	4½	8	...	...	...	...

Parker Utility Vises



For household and garage. Streamlined appearance, proper weight distribution, sturdy construction.

Stationary Base—Smooth Polished Jaws

No.	Each	Width Jaw In.	Jaw Opening In.	Pipe Capacity In.	Approx. Wt. Lbs.
183	2.00	3	3	Up to 1¼	9½

Swivel Base—Smooth Polished Jaws

No.	Each	Width Jaw In.	Jaw Opening In.	Pipe Capacity In.	Approx. Wt. Lbs.
83	2.50	3	3	Up to 1¼	11
83½	3.00	3½	3½	Up to 1½	13

Swivel Base—Replaceable Steel Jaws

No.	Each	Width Jaw In.	Jaw Opening In.	Pipe Capacity In.	Approx. Wt. Lbs.
93½	4.50	3½	4	Up to 1½	17
94	7.50	4	4½	Up to 2	28

Individually boxed